INSTRUCTION MANUAL

GR 1987

Minical Sound-Level Calibrator

GenRad

CONCORD, MASSACHUSETTS 01742

GenRad

WARRANTY

We warrant that this product is free from defects in material and workmanship and, when properly used, will perform in accordance with applicable GenRad specifications. If within one year after original shipment it is found not to meet this standard, it will be repaired or, at the option of GenRad, replaced at no charge when returned to a GenRad service facility. Changes in the product not approved by GenRad shall void this warranty. GenRad shall not be liable for any indirect, special, or consequential damages, even if notice has been given of the possibility of such damages.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

GenRad policy is to maintain product repair capability for a period of ten years after original shipment and to make this capability available at the then prevailing schedule of charges.

INSTRUCTION MANUAL

GR 1987

Minical Sound-Level Calibrator

Form 1987-0100-B

February, 1979

This instrument is capable of calibrating sound-level meters used for measurements required under Part 1910.95 "Occupational Noise Exposure," (Dept. of Labor) of the Code of Federal Regulations, Chap. XVII of Title 29 (36 F. R. 7006).

CONCORD, MASSACHUSETTS 01742

Specifications

Output Sound-Pressure Levels: 114 dB or 94 dB re 20 μPa† under reference conditions.

Output Frequency: 1000 Hz ±3%.

Reference Conditions: TEMPERATURE: 20°C (68°F). ATMOSPHERIC PRESSURE: 1013 mbar† (760 mm of Hg) (30 in. of Hg). RELATIVE HUMIDITY: 65%. MICROPHONE EFFECTIVE VOLUME: 0.5 cm^3 (.03 $in.^3$) (nominal for GR 1961 Electret-Condenser Microphone*).

Accuracy of Sound-Pressure Level: Under stated reference environment conditions, ±0.25 dB for cavity alone, or cavity when used with any adaptor (except 1-1/8-in. adaptor: ±0.5 dB).

Temperature Coefficient of Sound-Pressure Level: Less than ±0.02 dB/°C.

Power: Powered by 9-V alkaline battery; Mallory MN 1604 or Eveready 522 recommended. Battery provides at least 20 h continuous operation.

Environment: TEMPERATURE: −10 to +50°C (+14 to +122°F), operating; −40 to +70°C (−40 to +140°F), storage with battery removed. HUMIDITY: 0 to 90% RH, operating.

Mechanical: DIMENSIONS (wxhxd): Approximately 63x63x89 mm (2-1/2x2-1/2x3-1/2 in.). WEIGHT: Approximately 270 gm (9.5 oz).

Battery Test: Internal circuitry checks condition of battery continuously. Calibrator will not operate at all if battery voltage falls below acceptable range.

Microphone Coupling: Transducer cavity accommodates following 1-in. microphones: GR 1961 electret-condenser,* GR 1971 ceramic, Western Electric 640AA and Tokyo Riko MR103.

Accessories Supplied: Coupler-adaptor to accommodate GR 1962 1/2-in electret-condenser microphone* and GR 1983 Sound-Level Meter microphone; carrying pouch; 3 spare desiccant kits; battery; instruction manual.

Accessories Available: Adaptor set that includes coupler-adaptor for 3/8-in. GR 1954 Noise Dosimeter microphone, coupler-adaptors and "O" ring for 1-in., 1/2-in. and 1/4-in. B & K microphones, and coupler-adaptor for 1-1/8-in. Shure Brothers microphone.

---

† In the international system of units (SI), the unit of pressure is the pascal (Pa); 1 Pa = 1 N/m^2 = 10 dynes/cm^2 = 10^{-2} mbar.
Ref: "The International System of Units (SI)," U.S. Dept. of Commerce, National Bureau of Standards, NBS Special Publication 330. S.D. Cat. No. C 13. 10:330/2, U.S. GPO, Wash., D.C., 20402.

*U.S. Patent 4,070,741.

Condensed Operating Instructions

TO ACTIVATE THE INSTRUMENT

a. Set power switch to desired calibration level (94 dB or 114 dB).

b. Listen for 1-kHz audible tone. If no tone is present, replace battery (see para 2.4).

TO CALIBRATE A SOUND-MEASURING INSTRUMENT

a. Observe 1987 desiccant through window. If pale blue, satisfactory; if pink, replace desiccants (see para 2.5).

b. If microphone adaptor is required, insert it in 1987 cavity to fit microphone under test (see para 2.6).

c. Set instrument under test to 100 dB (if 1987 is set at 94 dB) or 120 dB (if 1987 is set at 114 dB). Instrument may be set to FAST or SLOW response and C or A weighting.

d. Place 1987 on microphone of instrument under test, read level and adjust its sensitivity. A pressure-to-free-field correction (see para 2.10) must be added to this reading for some microphones (refer to following table); this correction (in dB) is to be added to the reading of the instrument under test ***before*** comparing it with the calibrated output of the 1987 (either 94 dB or 114 dB).

Handbook of Noise Measurement

This book, by Dr. A.P.G. Peterson and Ervin E. Gross, Jr., of the GenRad Engineering Staff covers thoroughly the subject of noise and vibration measurement. Copies are available from GenRad at $9.00 each, postpaid in the United States and Canada.

GR P/N 5301-8111

PRESSURE-TO-FREE-FIELD CORRECTIONS*

Microphone Manufacturer and Type	GR Adaptor Used	Correction (dB)
Flat-Response-to-Random-Incidence Microphones:		
GR 1961-9610 or -9601 (1-in. electret)	none	0.0
GR 1962-9610 or -9601 (1/2-in. electret)	1987-7061	0.0
GR 1971 (1-in. ceramic)	none	0.0
GR 1983 Sound-Level Meter (1/2-in. ceramic)	1987-7061	0.1
GR 1954 Noise Dosimeter (3/8-in. ceramic)	1987-7076 and 1987-7095	0.0
Flat-Response-to-Perpendicular-Incidence Microphones:		
GR 1961-9611 or -9602 (1-in. electret)	none	0.3
GR 1962-9611 or -9602 (1/2-in. electret)	1987-7061	0.1
B & K 4131 (1-in. condenser)†	O-Ring (5855-6920)	0.2
B & K 4133 (1/2-in. condenser)	1987-2050	0.0
B & K 4135 (1/4-in. condenser)	1987-2060	0.0

*Measurement Conditions: Atmospheric Pressure, 760 mm (30 in.) of Hg (see para 2.9 for other pressures).

† Additional correction required due to microphone effective volume (refer to para 2.11).

TABLE OF CONTENTS

Specifications

Condensed Operating Instructions

Introduction — Section 1

1.1 Purpose 1
1.2 Description 1
1.3 Controls, Indicators and Connectors . 2
1.4 Accessories 2

Operation — Section 2

2.1 Unpacking and Inspection 7
2.2 Battery Installation 7
2.3 Battery Check 8
2.4 Battery Removal 10
2.5 Desiccant Replacement 10
2.6 Microphone Adaptors 12
2.7 Operational Check 14
2.8 Calibration of Instruments 15
2.9 Altitude and Pressure Corrections . . . 18
2.10 Pressure-to-Free-Field Corrections . . . 20
2.11 Microphone-Volume Correction . . . 22
2.12 Use with GR 1954 Noise Dosimeter . . 24

Theory — Section 3

3.1 General 25
3.2 Circuit Description 25

Service and Maintenance — Section 4

4.1 Customer Service 31
4.2 Instrument Return 31
4.3 Performance Verification 32
4.4 Disassembly 34
4.5 Test and Calibration 34
4.6 Trouble Analysis 36

Parts List and Diagrams — Section 5

5.1 Electrical Parts List and Diagrams . . . 37
5.2 Mechanical Parts 37
5.3 Federal Manufacturers' Codes 37

Introduction — Section 1

NOTE

Batteries shipped uninstalled. See para 2.2.

1.1 PURPOSE.

The GR 1987 Minical Sound-Level Calibrator is a compact, self-contained device for checking the calibration of sound-measuring instruments. It is intended for field use on a wide variety of sound-level meters, analyzers or sound-measuring systems that contain a microphone adaptable to its cavity.

1.2 DESCRIPTION.

The GR 1987 Minical produces a 1000-Hz tone at sound-pressure levels (SPL) of either 94 dB or 114 dB. An SPL of 94 dB represents the reference SPL* recommended in the forthcoming IEC Consolidated Revision Standard;† an SPL of 114 dB is sufficiently above most ambient noise or vibration sources to provide accurate calibration where these sources are present.

The 1987 features a ruggedized package that is resistant to moisture, dust and mechanical shock. The cavity of the 1987 will accommodate all GR 1-in. electret-condenser microphones, GR 1-in.

---

*The reference sound-pressure level is that level recommended by the manufacturer for calibrating the absolute sensitivity of a sound-level meter.

†Ref: "Draft: Instruments for the Measurement of Sound Level (Sound Level Meters)," to supersede IEC Publications 123, 179 and 179A upon final approval; International Electrotechnical Commission, 1 Rue de Varembé, Geneva, Switzerland.

Table 1-1
CONTROLS, INDICATORS AND CONNECTORS

Fig. 1-1 Ref.	Name	Description	Function
1	Battery Compartment	Recess in 1987 housing; access obtained by removing cover secured by thumbscrew.	Contains 9-V alkaline battery for providing instrument power.
2	94 dB/OFF/ 114 dB	3-position toggle switch.	OFF – disconnects instrument from its internal battery source. 94 dB – selects calibrated output level of 94 dB re 20 μPa. 114 dB – selects calibrated output level of 114 dB re 20 μPa.
3	Desiccant Window	Small, circular window on 1987 housing.	Provides observation of desiccant to determine its condition; pale blue means satisfactory, pink means replacement necessary.
4	Transducer Assembly	Contains electromagnetic transducer and 1-in. cavity for microphone insertion.	Provides acoustical output signal to calibrate a sound-measuring instrument; cavity allows tight acoustical coupling to a microphone.



Figure 1-1. Controls, indicators and connectors.

ceramic microphones, the Western Electric 640AA (or equivalent microphone) and the Tokyo Riko MR 103 microphone. The 1987 is also supplied with an adaptor that accommodates GR 1/2-in. electret-condenser microphones. An optional adaptor set (P/N 1987-9600) is available to accommodate the 3/8-in. microphone used on the GR 1954 Noise Dosimeter, the B & K 1-in., 1/2-in. and 1/4-in. microphones and the Shure Brothers' 1-1/8-in. microphone.

1.3 CONTROLS, INDICATORS AND CONNECTORS.

Figure 1-1 illustrates GR 1987 controls, indicators and connectors; Table 1-1 describes these items.

1.4 ACCESSORIES.

Model GR 1987-3000 signifies the Minical Sound-Level Calibrator only, with no accessories. Model GR 1987-9700 signifies the instrument included with the accessories illustrated in Figure 1-2 and described in Table 1-2. Figure 1-3 illustrates the six microphone adaptors included in the optional GR 1987-9600 Microphone Adaptor Set, an accessory available by order from GenRad; Table 1-3 describes these adaptors.



Figure 1-2. Accessories supplied with GR 1987-9700 (instruction manual not shown).

Table 1-2
ACCESSORIES SUPPLIED WITH GR 1987-9700

Description	GR P/N
Minical Sound-Level Calibrator, instrument only	1987-3000
Adaptor for 1/2-in. microphone	1987-7061
Battery, 9-V alkaline	8410-3400
3 Desiccant Kits (2 desiccant cartridges per kit)	5873-3001
Pouch	1987-0420
Instruction Manual	1987-0100



Figure 1-3. GR 1987-9600 Microphone Adaptor Set (available accessory).

Table 1-3
GR 1987-9600 MICROPHONE ADAPTOR SET

Description	GR P/N
Box (for adaptors below):	1987-1800
1954 Microphone Adaptor	1987-7076
1954 Microphone-Adaptor Cap	1987-7095
"O" Ring (for B & K Type 4131/32 1-in. microphone)	5855-6920
Adaptor (for B & K Type 4133/34 1/2-in. microphone)	1987-2050
Adaptor (for B & K Type 4135/36 1/4-in. microphone)	1987-2060
Adaptor (for Shure Bros. Model 98108 1-1/8-in. microphone)	1987-7066

Operation — Section 2

2.1 UNPACKING AND INSPECTION.

If the shipping carton is damaged, ask that the carrier's agent be present when the instrument is unpacked. Inspect the instrument for damage (scratches, dents, broken parts, etc). If the instrument is damaged or fails to meet specifications, notify the carrier and the nearest GenRad field office. (See list at back of this manual.) Retain the shipping carton and the padding material for carrier's inspection.

The battery must be installed in the 1987 to make it operable. Para 2.2 gives the procedure for battery installation.

A small circular window in the 1987 housing provides observation of a desiccant cartridge that is used for moisture control. If pale blue, the desiccant is satisfactory; if pink, replacement is necessary. Refer to para 2.5 for replacement procedures.

2.2 BATTERY INSTALLATION.

The 1987 is shipped with the battery removed. A 9-V alkaline battery is included with the accessories, and this is the only type of battery recommended for use that will provide an optimum operating life.* A new alkaline battery will provide approximately 20 h of continuous operation.

*GenRad recommends Mallory MN 1604 or Eveready 522.

To install the battery, proceed as follows (refer to Figure 2-1):

a. Loosen the thumbscrew (ccw direction) that secures the battery-compartment cover. This screw is captivated so that it will remain with the cover once loosened.

b. Grasp the thumbscrew and lift the cover away from the 1987 housing.

c. Before inserting the battery, observe its polarity with respect to the battery outline shown inside the compartment.

d. Push the bottom of the battery against the foam to compress it. Simultaneously push the other end of the battery (terminal end) into the compartment such that it is firmly seated and makes contact with the spring-metal contacts.

e. Replace the battery-compartment cover by sliding its rear edge under the rear-edge of the battery compartment until the thumbscrew lines up with its threaded hole in the 1987 housing. Then seat the cover flush on the lip that is built into the compartment, and tighten the thumbscrew (cw direction) to secure the cover to the unit.

2.3 BATTERY CHECK.

If the battery voltage is not adequate, there will either be no acoustical output, or the output will cut out after being on for a short time.

To check for sufficient battery voltage, proceed as follows:

a. Set the power switch to the 94-dB or 114 dB position.


ASSEMBLY-SCREW HOLES IN BATTERY COMPARTMENT
THREADED SPACERS (OFFSET FROM MIDDLE OF HOUSING) THAT ACCEPT ASSEMBLY SCREWS
ELECTROMAGNETIC TRANDUCER
94-dB ADJUSTMENT (R13)
114-dB ADJUSTMENT (R12)
DESICCANTS
LABEL AND NUT REMOVED FROM POWER SWITCH
BATTERY COMPARTMENT COVER
9-V ALKALINE BATTERY
ASSEMBLY SCREWS REMOVED FROM BATTERY COMPARTMENT

Figure 2-1. GR 1987 disassembled.

b. If the battery is up to operating voltage and the 1987 is functional, a tone of 1 kHz will be audible.

c. If this audible tone is not present, the battery should be replaced. Refer to para 2.4 and 2.2 for battery-removal and installation procedures.

2.4 BATTERY REMOVAL.

CAUTION

The battery should be removed whenever the 1987 will not be used for 6 months or more to prevent corrosion on the terminals.

To remove batteries for replacement or storage, proceed as follows (refer to Figure 2-1).

a. Loosen the captive thumbscrew (ccw direction) that secures the battery-compartment cover.

b. Grasp the thumbscrew and lift the cover away from the 1987 housing.

c. Place one finger, or tool like a small screwdriver, on the terminal end of the battery, and push it to compress the foam on the other end, with the same finger or tool, pull up slightly until the battery pops out.

2.5 DESICCANT REPLACEMENT.

The 1987 contains two desiccant cartridges inside its transducer section (refer to Figure 2-1) in order to keep the interior humidity low relative to any high external humidity. The desiccants are used to minimize the effects of humidity upon the transducer, which produces a more stable output

when dry. These two cylindrical cartridges are about 4 cm (1-5/8 in.) in length and 8 mm (3/8 in.) in diameter. One of the desiccants is visible through the small circular window on the 1987 housing; this desiccant will change color from pale blue to pink when it has absorbed moisture, and such an indication means that the two desiccants should be replaced by dry ones. Three spare desiccant kits (each kit contains two cartridges) are included with the accessories supplied; they are contained in an air-tight package.

The desiccants are made of a super-activated silica-gel (SO_2) fill. They have a high moisture-absorption capability and are fast drying. They can be rejuvenated by baking at 80°C (170°F) until they turn blue. To replace the desiccants, proceed as follows (refer to Figure 2-1):

a. Remove the battery-compartment cover and battery (detailed in para 2.4).

b. Remove the two Phillips-head screws that are visible inside the compartment once the battery has been removed.

c. Grasp the bottom section of the 1987 with one hand, the top section with the other, and pull off the top section; the separation will occur at the rubber gasket between the two sections.

d. Each desiccant cartridge is held in place on the transducer-housing assembly by two clips, one on each end (see Figure 2-1). To replace a desiccant, slide it out from under the clips, and then slide a replacement cartridge back under the clips.

e. Before reassembling the transducer assembly, check to see if the two wires that connect to the transducer became unplugged. If so, they should be connected to the terminals labelled WT1 and WT2 on the circuit board. These two connections are nonpolarized and interchangeable (refer to Figure 4-1).

f. Replace the top section of the 1987 on the lower section. Note that the two spacers (see Figure 2-1) that accept the Phillips-head screws are offset from the center of the housing such that there is only one orientation that mates the top section with the bottom section. Both the top and bottom sections should be firmly seated into the rubber gasket before the two Phillips-head screws are tightened; after securing these two screws, make sure the gasket has seated properly. (It can be properly seated by running a fingernail around its edge.)

g. Replace the battery and battery-compartment cover.

2.6 MICROPHONE ADAPTORS.

2.6.1 General.

The cavity of the 1987 will accommodate the following 1-in. microphones: the GR 1961 Electret-Condenser, the GR 1971 Ceramic, the Western Electric 640AA, and the Tokyo Riko MR103. Adaptors must be used for other-sized microphones.

The 1/2-in. microphone adaptor, P/N 1987-7061, is an accessory included with the 1987. It must be inserted into the cavity of the transducer assembly when calibration is being performed on an instrument with a GR 1/2-in. electret-condenser

microphone. Adaptors for microphones other than GR 1/2-in. and 1-in. microphones are available in an accessory kit, P/N 1987-9600, which is described below.

The GR 1987-7061 Microphone Adaptor is inserted by gently pushing it into the cavity until the three detents inside the cavity fall into the groove around the outside of the adaptor. Make sure it is firmly seated. To remove the adaptor, grasp its outer flange that extends out of the cavity, and pull it out.

2.6.2 GR 1987-9600 Microphone Adaptor Set.

This optional set is an accessory available by order from GenRad. It includes six microphone adaptors that are necessary to accommodate various microphones on instruments under test. The base of each adaptor is marked with its appropriate part number; Figure 1-3 and Table 1-3 illustrate and describe the adaptors in this set.

The six adaptors in this set are inserted in the transducer cavity as described below:

- GR 1987-2050 Microphone Adaptor for B & K Type 4133/34 1/2-in. microphone: insert in same manner as 1987-7061 adaptor. This adaptor appears similar to the GR 1987-7061 1/2-in. adaptor, except for an O-ring and minor dimensional differences inside the B & K adaptor.

  NOTE

  The GR 1987-2050 and GR 1987-7061 adaptors are *not* interchangeable.

- GR 1987-2060 Microphone Adaptor for B & K Type 4135/36 1/4-in. microphone: insert in the same manner as 1987-7061 adaptor.

- GR 1987-7066 Microphone Adaptor for Shure Bros. Model 98108 1-1/8-in. microphone: insert in the same manner as 1987-7061 adaptor.
- GR 5855-6920 O-ring for B & K Type 4131/32 1-in. microphone: place it in the cavity and, with the index finger, work it into the groove all the way around the inside of the cavity.
- GR 1987 7076 Microphone Adaptor and GR 1987-7095 Adaptor Cap for 3/8-in. microphone (used on GR 1954 Noise Dosimeter) — proceed as follows:

a. Set the microphone cap (P/N 1987-7095) flat side down on a bench or table.

b. Insert the 3/8-in. microphone into the cap with the front side up. Make sure the microphone cable slides into the groove on the side of the cap as the microphone is inserted.

c. Place the GR 1987-7076 Microphone Adaptor over the cap such that the groove in the side of the adaptor fits over the cable from the microphone.

d. Insert the microphone-cap-adaptor assembly into the 1987 transducer cavity in the same manner as the adaptor described in para 2.6.1 was installed.

CAUTION

The transducer should not be in contact with a surface subject to vibration when calibration is performed. This can introduce an ambient level significant enough to give a false calibration indication.

2.7 OPERATIONAL CHECK.

To quickly check the operation of the 1987 before using it, proceed as follows:

a. Turn the power switch from OFF to the 94-dB position, and listen for a 1000-Hz audible tone; this indicates that the instrument is working. If no tone is evident, the battery may need replacement; refer to para 2.4 for battery replacement.

b. Change the switch from 94 dB to 114 dB; the 20-dB increase in level of the 1000-Hz tone should be easy to detect audibly.

2.8 CALIBRATION OF SOUND-MEASURING INSTRUMENTS.

2.8.1 General.

Before a sound-level meter or analyzer is used to make a measurement or analysis, its sensitivity should be checked.

The 1987 Minical Sound-Level Calibrator provides a calibrated output to ensure that the sensitivity of a particular piece of sound-measuring equipment (including microphone) is properly adjusted. The 1987 generates two levels of output, 94 dB and 114 dB re 20 μPa, at a frequency of 1000 Hz.

2.8.2 Calibration.

The sensitivity of a sound-level meter or analyzer is checked by placing the transducer cavity of the 1987 over the microphone of the instrument under test. The instrument is then adjusted to indicate the known level, either 94 dB or 114 dB. Figure 2-2 shows the setup for this sensitivity check with a typical sound-level meter. The following procedure is suggested as a means to check and adjust the sensitivity of an instrument.

Figure 2-2. Typical calibration setup.

CAUTION

Ambient sources of noise or vibration can cause a false calibration indication; this can be especially significant at the lower 94-dB level.

a. Insert the proper adaptor, if one is required, into the cavity of the 1987 to fit the particular microphone under calibration (refer to Table 1-3).

b. Set the 1987 power switch to the 94-dB or 114-dB position, depending on the desired level of calibration. (Select the level closest to the upper limit of the level range intended for measurement.)

c. An audible tone of 1 kHz should be present from the calibrator; if not, the battery may need replacement (refer to para 2.4).

d. Place the 1987 Minical over the microphone of the sound-measuring instrument being calibrated.

e. On the instrument under test, set the LEVEL RANGE control to the range having 100 dB as its upper limit if 94 dB was selected on the 1987; or, if 114 dB was selected on the 1987, choose a range with an upper limit of 120 dB. The instrument may be set to FAST or SLOW response and C or A weighting.

f. Read the level on the instrument under test, and adjust the sensitivity control for the correct indication of the 1987 level selected in step e. It is important to note that a pressure-to-free-field correction must be made to this indication for some microphones (this subject is discussed in para 2.10). Normal variation of temperature and atmospheric pressure will have negligible effect on the sound-pressure level developed from the 1987. Altitude-pressure corrections are given in para 2.9; these must be taken into account for a calibration made well above sea level.

g. An example of a pressure-to-free-field correction follows:

Condition of measurement —
Microphone Type GR 1962-9611 (1/2-in. electret, flat perpendicular).
Correction from Table 2-1 —
0.1 dB.

For this example, adjust the sensitivity of the instrument under test for an indication 0.1 dB below the level selected on the 1987. For example, if the 1987 is set to 94 dB, adjust the instrument's sensitivity for a reading of 93.9 dB.

2.9 ALTITUDE AND PRESSURE CORRECTIONS.

The acoustical output of the 1987 is equal to 94 dB or 114 dB, depending on the selection, at a normal atmospheric pressure of 760 mm (30 in.) of Hg at sea level. A correction must be made to the output if the instrument is used at a pressure other than this normal pressure. Figure 2-3 shows a correction curve that indicates the change in sound-pressure level (SPL) for a change in altitude and atmospheric pressure. (Most barometers are calibrated to read pressures corrected to sea level.)

An example of how to use Figure 2-3 follows

Condition of Measurement —
Altitude of 2.4 km (8000 ft)
Correction from Figure 2-3 —
-1.5 dB

For this example, the acoustical output of the 1987 is 1.5 dB less than the indication on the power switch. That is, the 1987 SPL would be 92.5 dB for a power-switch setting of 94 dB or 112.5 dB for a setting of 114 dB. Therefore, the sensitivity of the instrument under test would be adjusted for a reading of either 92.5 dB or 112.5 dB in this example.



Figure 2-3. Variation in sound-pressure level with a change in altitude and atmospheric pressure.

2.10 PRESSURE-TO-FREE-FIELD CORRECTIONS.

When the 1987 transducer is tightly coupled to a microphone within its cavity, it creates a microphone frequency-response condition referred to as "pressure response." Pressure response is characterized by a sound field that produces a uniform sound pressure over the diaphragm surface of a microphone. This condition is realized by the 1987 when the microphone being calibrated is tightly coupled within its specially shaped cavity of small volume.

Most microphones used in sound-measuring instrumentation are designed for one of two kinds of response: either a flat-frequency response to sounds of random incidence in a free field, or a flat-frequency response to sounds of perpendicular (with respect to the plane of the microphone's diaphragm) incidence in a free field. Since such free-field incidence is not simulated by the 1987, with its tight pressure coupling within a cavity of small dimensions, correction factors are sometimes necessary for either of these two types of microphone when calibrated with the 1987.

The amount of correction factor that is required depends on the type of microphone being calibrated. Table 2-1 gives the pressure-to-free-field corrections that are necessary for various microphones. These corrections factors are computed from the difference between the perpendicular or random response that a microphone is designed for, and the actual pressure response within the cavity of the 1987. Thus, a correction will always result in adjusting the sensitivity of the instrument under test for a reading lower than the level indicated on the 1987 label by the power switch.

Table 2-1
PRESSURE-TO-FREE-FIELD CORRECTIONS*

Microphone Manufacturer and Type	GR Adaptor Used	Correction$^{\Delta}$ (dB)
Flat-Response-to-Random-Incidence Microphones:		
GR 1961-9610 or -9601 (1-in. Electret)	none	0.0
GR 1962-9610 or -9601 (1/2-in. Electret)	1987-7061	0.0
GR 1971 (1-in. Ceramic)	none	0.0
GR 1983 Sound-Level Meter (1/2-in. Ceramic)	1987-7061	0.1
GR 1954 Noise Dosimeter (3/8-in. Ceramic)	1987-7076 and 1987-7095	0.0
Flat-Response-to-Perpendicular-Incidence Microphones:		
GR 1961-9611 or -9602 (1-in. Electret)	none	0.3
GR 1962-9611 or -9602 (1/2-in. Electret)	1987-7061	0.1
B & K 4131 (1-in. Condenser)†	O-Ring (5855-6920)	0.2
B & K 4133 (1/2-in. Condenser)	1987-2050	0.0
B & K 4135 (1/4-in. Condenser)	1987-2060	0.0

• Measurement Conditions:
Atmospheric Pressure, 760 mm (30 in.) of Hg.
Temperature, +20°C (68°F).

$^{\Delta}$To be added to sound-pressure level indication of meter under test before it is compared with level indicated on 1987 label by power switch.

†Additional correction required due to microphone effective volume (refer to para 2.11).

Sound-level meters that comply with the ANSI S1.4-1971* standard use a microphone idealized for a random-incidence response, whereas meters that comply with the IEC† standards use a microphone idealized for a perpendicular-incidence response.

2.11 MICROPHONE-VOLUME CORRECTION.

The sound-pressure level (SPL) developed in the 1987 transducer cavity is dependent upon the volume of air between the diaphragm of the microphone being calibrated and the diaphragm of the 1987 transducer. A portion of that volume between the two diaphragms, namely, the particular volume comprised by the space between the front face of the microphone and its diaphragm, is referred to as the "microphone effective volume."

The 1987 transducer cavity is designed to produce a 94-dB or 114-dB SPL upon the diaphragm of a 1-in. microphone that has an "effective volume" of 0.5 cm^3 (.03 $in.^3$). The 1-in. GR 1961 Electret-Condenser Microphone has this idealized effective volume, and thus requires no correction

---

*Ref: "American National Standard Specification for Sound Level Meters," ANSI S1.4-1971, published 1971, American National Standard Institute, Inc., 1430 Broadway, New York, N.Y. 10018.

†Ref: "Recommendations for Sound Level Meters," Publication 123, published 1961;
"Precision Sound Level Meters," Publication 179, published 1973;
"Precision Sound Level Meters, Additional Characteristics for the Measurement of Impulsive Sounds," Publication 179A, published 1973;
International Electrotechnical Commission, 1 Rue de Varembe, Geneva, Switzerland.

to the SPL when it is calibrated by the 1987. Also, no microphone-volume correction is necessary for other GR 1-in. electret-condenser microphones, GR 1-in. ceramic microphones, the Western Electric 640AA microphone or the Tokyo Riko MR103 microphone.

The microphone effective volume of the 1-in. B & K 4131/4132 Microphone has a significant enough discrepancy from the idealized volume (0.5 cm^3) that a microphone-volume correction is necessary. This correction is given in Table 2-2; it should be added to the SPL indication on an instrument that utilizes the 4131/32 microphone when that instrument is calibrated by the 1987.

When the 1/2-in. microphone adaptor (P/N 1987-7061, supplied with the 1987) is used to calibrate a GR 1/2-in. electret-condenser microphone, no microphone-volume correction is necessary. Likewise, when any of the adaptors (except the 5855-6920 O-ring adaptor for the B & K 4131/32 Microphone cited above) included in the optional GR 1987-9600 Microphone Adaptor Set are used with their intended microphones (refer to Table 1-3), no microphone-volume correction is necessary.

Table 2-2
MICROPHONE-VOLUME CORRECTION*

Microphone Type	Adaptor Used	Correction (dB)
B & K 4131/32 (1-in. Condenser)	O-Ring (5855-6920)	0.4

*To be added to the sound-pressure-level indication of the meter under test.

2.12 USE WITH GR 1954 NOISE DOSIMETER.

The calibration of the monitor on the GR 1954 Noise Dosimeter can be checked using the 1987 in place of the 1954 Indicator's calibrator. The GR 1987-7076 Adaptor and GR 1987-7095 Adaptor Cap are required; these are included in the GR 1987-9600 Microphone Adaptor Set.

The calibration procedure follows:

a. Insert the 1954 Monitor into the 1954 Indicator as normally done for a routine calibration check (refer to the 1954 Instruction Manual).

b. Set the dB RANGE switch on the 1954 Monitor to 80-130 dB, and the ON/HOLD switch to ON.

c. Insert the 1954 Microphone into the 1987 cavity, using the 1987-7076 Adaptor and 1987-7095 Adaptor Cap (refer to para 2.6.3 for instructions on installing adaptors).

d. Set the power switch on the 1987 to 114 dB.

e. Reset the monitor by depressing DISPLAY and RESET simultaneously on the indicator.

f. Depress the CALIBRATE button on the 1954, and hold it for 10 s until the display reaches a steady value. Adjust the CAL control on the monitor for a reading on the indicator of **0.087.** This number applies to the 1954-9710 Monitor, which has a 5-dB exchange rate. The calibration number of the 1954-9730 Monitor is 0.78.

A cross-check of the above calibration can be made by comparing the results using the 1987 calibrator with the results using the 1954 Indicator's calibrator. Some discrepancy is likely, and the tolerance of the 1987 output level and the 1954 Indicator output level must be taken into account when making this comparison.

Theory – Section 3

3.1 GENERAL.

The 1987 Minical calibrator is a single-frequency, secondary-standard* sound source that can calibrate sound-level meters in the field. The 1987 provides the user a quick means of checking sound-level meters at 1 kHz and at two reference sound-pressure levels: 114 dB and 94 dB. The 1987 calibrates 1-in. (nominal) microphones directly without an adaptor, and a variety of other standard microphones with adaptors supplied or available as accessories.

3.2 CIRCUIT DESCRIPTION.

3.2.1 General.

Figure 3-1 is a block diagram of the 1987; etched-board and schematic diagrams are given in Section 5. All of the electrical components, except the transducer and battery, are contained on the calibrator's only etched board (P/N 1987-4700), shown in Figure 4-1. The block diagram shows the following main elements of the 1987 circuitry:

- battery and power-supply splitter
- battery-low test circuit
- bridge oscillator
- transducer driver

The paragraphs below discuss these circuits.

---

*As differentiated from a "primary-standard" calibrator that contains a transducer with a known level of response traceable to the National Bureau of Standards (see para 4.5).



Figure 3-1. Block Diagram.

3.2.2 Battery and Power-Supply Splitter.

The power source for the 1987 is a single 9-V alkaline battery. Approximately 20 h of continuous operation are available from a new battery. Since the operational-amplifier circuits require both plus and minus supplies, the battery output is split into equal positive and negative voltages by resistors R1 and R2 and "splitter" U1B (the output of U1B is the reference for ground). Capacitors C1 and C2 provide filtering as the battery's impedance increases with discharge.

3.2.3 Battery-Low Test Circuit.

This circuit is comprised of U1C, Q1, CR1 and CR2. The purpose of the circuit is to detect the power-supply output and disable the bridge-oscillator circuit for a low or dead battery. This results in an automatic-shutdown capability to prevent the 1987 from generating a low-level, out-of-calibration or drifting signal because of insufficient battery power. This is especially important if the 1987 is used as a system calibrator where it is left unattended while the system levels are monitored and adjusted.

The battery-low detector works as follows. The battery voltage is impressed across the current-source, Q1, and the 5-V Zener, CR1 (which has a low temperature coefficient). When the battery voltage is 9.0 V, the voltage at the cathode of CR1 is 0.5 V (-4.5 V plus 5.0 V), then the voltage at the input to the comparator (U1C) is 1.5 V below the cathode of CR1, or -1.0 V, causing CR1 to conduct. If the battery voltage has a 1.5-V drop from 9.0 V to 7.5 V, the anode voltage of CR1 becomes -3.5 V, and its cathode voltage becomes +1.5 V; now the comparator input voltage drops

to 0 V (1.5 - 1.5 V), causing its output voltage to also drop. When the output of U1C shifts to a low voltage, CR2 conducts; this places an added load on the oscillator-feedback circuit, causing oscillations to cease.

3.2.4 Bridge Oscillator.

The bridge-oscillator circuit is comprised of a 1-kHz bandpass filter (U1A), a soft limiter (R8, CR3 and CR4) and a temperature-compensating attenuator (R4 and R3/R14). The bandpass filter, U1A, is an active-filter operational amplifier with a bridge-null network in the feedback loop. The overall center frequency, stage gain and Q are determined by the ratios of the five bridge components. The phase shift across the network is zero at center frequency. The stage gain is approximately 34 dB. In order to make the circuit oscillate, the output of U1A is returned to its noninverting terminal through an appropriate attenuator.

The soft limiter, consisting of R8, CR3 and CR4, limits the output of the bandpass filter to ensure long-term stability. If the U1A output were fed back directly to its input without passing through this limiter, oscillation would still occur, but would build up in amplitude until limited by the output swing of U1A. The soft limiter maintains the U1A output at a constant level of approximately 1.2 V pk-pk. The distortion produced by the limiting is later filtered by the 1-kHz bandpass filter.

The "soft" limited signal is attenuated by R4 and R3/14. The latter two resistors, R3 and R14, are used to temperature-compensate the natural temperature-shift effects of CR3 and CR4. The

net attenuation in this positive feedback load is slightly less than the gain of the bridge filter to ensure that the oscillator starts.

3.2.5 Transducer Driver.

This circuit is comprised of two level adjustments (R12 and R13) and a current-source amplifier (U1D). The output of the 1-kHz oscillator is selected by one side of the 114dB/OFF/94dB switch (S1) and is fed through one of two paths to the current-summing node of operational-amplifier U1D. Each path has a gain control for adjusting the calibration of the 1987; R12 provides adjustment of the 114-dB level, and R13 is the 94-dB level adjustment (refer to para 4.5 and Figure 4.1).

The current-source amplifier, U1D, is used to drive the output transducer, LS-1, which provides the acoustical output to a sound-measuring instrument under test. Since the transducer is an electromagnetic device with an acoustical output proportional to the current in its magnetic field, it is placed in the amplifier feedback loop, which provides a constant-current source. If the transducer had been driven from a voltage source, the current in the field would have depended on the coil-winding resistance, which is temperature dependent.

Capacitor C6 is used to roll off high frequencies, thus eliminating some upper harmonics. Resistor R10 allows testing of the transducer current at TP2.

Service and Maintenance — Section 4

CAUTION

The servicing instructions in this section should be performed by qualified personnel only.

4.1 CUSTOMER SERVICE.

Our warranty (at the front of this manual) attests the quality of materials and workmanship in our products. If malfunction does occur, our service engineers will assist in any way possible. If the difficulty cannot be eliminated by use of the following service instructions, please write or phone the nearest GenRad service facility (see back page), giving full information of the trouble and of steps taken to remedy it. Describe the instrument by name, catalog number, serial number, and ID (IOT) number if any. (Refer to front and rear panels.)

4.2 INSTRUMENT RETURN.

4.2.1 Returned Material Number.

Before returning an instrument to GenRad for service, please ask our nearest office for a "Returned Material" number. Use of this number in correspondence and on a tag tied to the instrument will ensure proper handling and identification. After the initial warranty period, please avoid unnecessary delay by indicating how payment will be made; i.e., send a purchase-order number.

4.2.2 Packaging

To safeguard your instrument during storage and shipment, please use packaging that is adequate to protect it from damage, i.e., equivalent to the original packaging. Any GenRad field office can advise or provide packing material for this purpose. Contract packaging companies in many cities can provide dependable custom packaging on short notice. Here are two recommended packaging methods.

Rubberized Hair.

Cover the painted surfaces of the instrument with protective wrapping paper. Pack the instrument securely in a strong protective corrugated container, which has a 25-kg/cm (350-lb/sq in.) bursting test, with 5-cm (2-in.) rubberized hair pads placed along all surfaces of the instrument. Insert fillers between the pads and the container to ensure a snug fit. Mark the box "Delicate Instrument" and seal it with strong tape.

Excelsior.

Cover the painted surfaces of the instrument with protective wrapping paper. Pack the instrument in a strong corrugated container, which has a 25-kg/cm (350-lb/sq in.) bursting test, with a layer of excelsior about 15-cm (6-in.) thick packed firmly against all surfaces of the instrument. Mark and seal the box as described above.

4.3 PERFORMANCE VERIFICATION.

The following procedure is intended as a quick check of the 1987, and is distinct from the test and calibration procedures in para 4.5 that require

accuracy traceability to the National Bureau of Standards. A precision sound-level meter, such as the GR 1982 or its equivalent, should be used for this performance test.

a. The calibration of the 1982 should first be checked, and adjusted if necessary, using another calibrator with a known accuracy correct to within ±0.5 dB. A GR 1986, GR 1562 or GR 1567 can be used for this purpose. To calibrate the 1982, set its controls as follows:

Power Switch . . . . . ON
DIGITAL DISPLAY: . . . . . cont
OCTAVE FILTER FREQ: . . . . 1 k (Hz)
dB RANGE: 70-120
DETECTOR: . . . . . FAST

b. Set the controls on the calibrator being used to a level of 114 dB and a frequency of 1 kHz. Install the appropriate microphone adaptor in the calibrator being used to accommodate the 1/2-in. microphone on the 1982, and then carefully place the calibrator over the microphone of the 1982.

c. Observe the 1982 digital display, and adjust its CAL control for a reading of exactly 114.0 dB. The 1982 is now accurately calibrated to within ±0.5 dB.

d. Insert the 1/2-in. microphone adaptor (P/N 1987-7061) in the 1987 transducer cavity.

e. On the 1987 under test, set the 114dB/OFF/94dB power switch to 114 dB, and then carefully mount the calibrator over the microphone of the 1982.

f. Observe the reading on the 1982; it should be 114 dB, ±0.5 dB.

g. Select the 94-dB level on the 1987. Again observe the reading on the 1982; it should be 94 dB, ±1.25 dB. The wider tolerance allows for linearity errors within the sound-level meter itself.

Any 1987 that fails to perform properly should be returned to an authorized GenRad service facility, as described in para 4.1 and 4.2.

4.4 DISASSEMBLY.

The circuitry of the 1987 is contained on one small board. To gain access to this board, which is normally required for troubleshooting procedures only, proceed as follows:

a. Disassemble the housing of the 1987 as described in para 2.5 and Figure 2-1.

b. In order to remove the board, first remove the nut and lockwasher that secure the power switch (toggle switch) to the housing of the 1987.

c. Remove the one screw on the component side of the board; this will allow the board to drop out of the housing.

d. The board can be powered externally by connecting a 9-Vdc supply or battery to WT3(+) and WT4(–) (see Figure 4-1).

4.5 TEST AND CALIBRATION.

Special facilities are required to calibrate the output level of the 1987 Minical so that it, in turn, can be used to calibrate sound-measuring instruments in accordance with ANSI and IEC standards. Such facilities are available at the GenRad factory and service centers, and are used in the initial factory calibration or repair of the 1987 units. These facilities must include a standard microphone, such as the Western Electric Co. Type 640AA or its



Figure 4-1. Circuit board (P/N 1987-4700).

equivalent, that possess a known level of response traceable to the National Bureau of Standards.

Potentiometers R12 and R13 are gain controls that are used to adjust the 114-dB and 94-dB levels, respectively, re 20 μPa. These two controls should not be tampered with unless a full calibration facility exists. The two adjustments are accessible from the top of the instrument when the power-switch plate is removed; this is accomplished by first taking off the nut and lockwasher that secure the small toggle switch to the housing, and then lifting the switch plate off of the unit. The two adjustments referred to are each covered by an adhesive disk; when the disks are removed, the adjustments are accessible through the two small holes in the top housing, one on each side of the switch (see Figure 2-1).

4.6 TROUBLE ANALYSIS.

When a malfunction is suspected in the 1987, it is first recommended that the performance-verification procedure of para 4.3 be conducted. This will usually establish if there is a problem with the unit. The 1987 should only be worked on by personnel skilled in the repair of delicate electronic equipment.

A detailed schematic diagram and parts list are included in Section 5, and circuit descriptions in Section 3. The schematic includes waveforms and voltages to aid in troubleshooting. If the 1987 undergoes any repair that will alter its acoustical output, it is essential that recalibration be performed. This is described in para 4.5. It is important to note that a special calibration facility is required for this procedure.

Parts Lists and Diagrams — Section 5

5.1 ELECTRICAL PARTS LIST AND DIAGRAMS.

Figures 5-1 and 5-2 are, respectively, an etched-board diagram and a schematic diagram of the circuits and components in the 1987. An electrical parts list gives descriptions and part numbers for the electrical components shown in these figures.

5.2 MECHANICAL PARTS.

Figure 5-3 shows locations of mechanical parts on the 1987 and the accompanying table gives their descriptions and associated GR and manufacturers' part numbers.

5.3 FEDERAL MANUFACTURERS' CODE.

The federal manufacturers' code numbers for part-number identification codes are listed at the end of this section.

NOTE

Electrical-parts information in this section is presented in such a way that all component and circuit data are visible in a single opening of the manual. Thus, the part-location diagram appears on a left-hand page, while the parts list and schematic diagram are on a right-hand apron and tip-out page.



Figure 5-1. Etched-board assembly (viewed from component side).

ELECTRICAL PARTS LIST

CALIBRATOR PC BOARD P/N 1987-4700

REFDES		DESCRIPTION	PART NO.	FSC	MFGR PART NUMBER
C	1	CAP TANT 120 UF 20PCT 10V	4450-5616	56289	150D127X0010R2
C	2	CAP TANT 120 UF 20PCT 10V	4450-5616	56289	150D127X0010R2
C	3	CAP CER MONO 0.1UF 20PCT 50VSP	4400-2050	72982	8131-M05J-651-104M
C	4	CAP MICA 3591 PF 1PCT 500V	4851-0272	72136	DM20FD3591PF1PCT4CR
C	5	CAP MICA 3591 PF 1PCT 500V	4851-0272	72136	DM20FD3591PF1PCT4CR
C	6	CAP CER MONO 0.1UF 20PCT 50VSP	4400-2050	72982	8131-M05J-651-104M
CR	1	ZENER DOXXXX 5.0V 1PCT .4W	5083-1102	24655	6083-1102
CR	2	DIODE 1N4151 75PIV IR.10A SI	6082-1001	14433	1N3634
CR	3	DIODE DA1703 40PIV IR 50UA SI	6082-1049	14433	1N4152
CR	4	DIODE DA1703 40PIV IR 50UA SI	5082-1049	14433	1N4152
Q	1	TRANS E-501 CS.33MA TO106	8215-0100	17856	E501
R	1	RES COMP 100 K 5PCT 1/4W	6099-4105	81349	RCR07G104J
R	2	RES COMP 100 K 5PCT 1/4W	6099-4105	81349	RCR07G104J
R	3	RES SILICON 500 OHM 10 PCT	5740-111J	25008	TG 1/8
R	4	RES FLM 15.4K 1 PCT 1/8W	6250-2154	81349	RN55D1542F
R	5	RES COMP 1.0 M 5PCT 1/4W	6099-5105	81349	RCR07G105J
R	6	RES FLM 453K 1 PCT 1/8W	6250-3453	81349	RN55D4533F
R	7	RES FLM 4.22K 1 PCT 1/8W	6250-1422	81349	RN55D4221F
R	8	RES FLM 12.7K 1 PCT 1/8W	6250-2127	81349	RN55D1272F
R	9	RES FLM 150 OHM 1 PCT 1/8W	6250-0150	81349	RN55D150JF
R	10	RES FLM 10 OHM 1 PCT 1/8W	6250-9100	81349	RN55D10R0F
R	11	RES FLM 1.4K 1 PCT 1/8W	6250-1140	81349	RN55D1401F
R	12	POT CERM TRM 200OHM 20PCT 4T	6049-0424	80294	3339P-W97-201
R	13	POT CERM TRM 2K 20PCT 4T	6049-0425	80294	3339P-W97-202
R	14	RES FLM 301 OHM 1 PCT 1/8W	6250-0301	81349	RN55D301JF
R	15	RES FLM 75K 1 PCT 1/8W	6250-2750	81349	RN55D7502F
R	16	RES FLM 178K 1 PCT 1/8W	6250-3178	81349	RN55D1783F
R	17	RES COMP 150 K 5PCT 1/4W	6099-4155	81349	RCR07G154J
R	18	RES COMP 1.0 K 5PCT 1/4W	6099-2105	81349	RCR07G102J
R	19	RES COMP 5.1 K OHM 5PCT 1/4W	6099-2515	81349	RCR07G512J
S	1	SWITCH TOG MIN 3POS DPDT +T+TITE	7910-0540	95146	TT00259
U	1	ICL CA3240 14D QUAD OP AMP	5432-1056	86684	CA3240

REFERENCE DESIGNATOR ABBREVIATONS

B	= Motor	P	= Plug
BT	= Battery	Q	= Transistor
C	= Capacitor	R	= Resistor
CR	= Diode	S	= Switch
DS	= Lamp	T	= Transformer
F	= Fuse	U	= Integrated Circuit
J	= Jack	VR	= Diode, Zener
K	= Relay	X	= Socket for Plug-In
KL	= Relay Coil	Y	= Crystal
KS	= Relay Switch	Z	= Network
L	= Inductor		
M	= Meter	References	
MK	= Microphone	ASA Y32 16 and MIL-STD 16C	



Figure 5-2. Schematic diagram.

Figure 5-3. Mechanical parts.



MECHANICAL PARTS

Qty.	Fig. 5-3 Ref. No.	Name	Description/Purpose	GR P/N	Fed. Mfg. Code	Mfg. P/N
2	1	Pad, Foam	Has one adhesive side; locates and cushions battery.	1987-7035	24655	1987-7035
1	2	Desiccant Kit	Silica-gel (SO_2) cartridges, two each per kit, provides humidity control.	5863-3001	24655	5863-3001
1	3	Transducer Assembly	Electromagnetic, provides acoustical output.	1987-1000	24655	1987-1000
2	4	Spacer	0.112-40 thread both ends; accepts screw securing top housing to bottom housing.	1987-6010	24655	1987-6010
1	5	Hex Nut	No. 10-48, part of 7910-0540 toggle switch.	7910-0540	95146	TT00259
1	6	Label, Power Switch	Steel, indicates sound-pressure level.	1987-0405	14655	1987-0405
1	7	Adaptor, Microphone	Plastic, adaptor for 1/2-in. microphone.	1987-7061	24655	1987-7061
2	8	Screw	0.112-40 x 0.375, Phillips-head, inserts in hole in battery compartment and threads into 1987-6010 spacer	7044-1103	24655	7044-1103
1	9	Bottom Housing Assembly	Plastic; contains transducer, 1-in. cavity and desiccants.	1987-1005	24655	1987-1005
1	10	Gasket, Housing	Styrene butadiene elastomer, provides moisture and dust control.	1986-7045	24655	1986-7045
1	11	Battery	9-V alkaline, provides power to instrument.	8410-3400	90303	MN1604INS
1	12	Frame, Window	Styrene butadiene elastomer, provides moisture and dust control.	1987-7085	24655	1987-7085
1	13	Window, Desiccant	Clear plastic, provides observation of desiccant.	1987-7090	24655	1987-7090
1	14	Cover, Battery Compartment	Aluminum, covers battery compartment.	1987-2000	24655	1987-2000
1	15	Screw, Cover	0.112-40 thread; secures battery-compartment cover.	1987-6001	14655	1987-6001
1	15	Bushing, Knurled	Fits over head of 1987-6001 screw.	1987-6005	24655	1987-6005
1	16	Top Housing Assembly	Plastic, contains battery compartment, power switch and etched board.	1987-2010	24655	1987-2010
1	17	Switch, Toggle	DPDT Power switch S1; 94d8/OFF/114d8, includes No. 10-48 hex nut and lock washer.	7910-0540	95146	TT00259

Appendix

USE OF THE NOMOGRAPH

CORRECTION OF BAROMETRIC PRESSURE TO STATION ALTITUDE.

To obtain a corrected barometric pressure for a station:

a. Determine the station's altitude above sea level.

b. Obtain a barometric pressure reading corrected to sea level from a barometer. (If the barometer reads only values in millimeters, find the corresponding value of millibars from the right-hand scales.

c. Place a straight-edge across the proper points on the center and left-hand scales of the nomograph, and read the actual pressure at the station, on the right-hand scales.

CONVERSION FROM MILLIMETERS OF MERCURY TO INCHES OF MERCURY.

To convert from millimeters of mercury to inches of mercury proceed as follows:

a. Find the barometric pressures value in millimeters of mercury on the right-hand scales.

b. Obtain the corresponding value in millibars from the same scales.

c. Move to the left-hand scales and find the millibar value obtained in step b.

d. Read the corresponding value of barometric pressure in inches of mercury from the left-hand scales.

NOMOGRAPH FOR APPLYING ALTITUDE CORRECTION TO BAROMETRIC PRESSURE



NOTE

1 foot =0.3048 meters

FEDERAL SUPPLY CODE FOR MANUFACTURERS

From Defense Logistics Agency Microfiche

H4-2 SB 708-42 GSA-FSS H4-2

Ref FMC Column in Parts Lists

07910	Cont Device., Hawthorne, CA 90250
14433	ITT, W. Palm Beach, FL 33402
17856	Siliconix, Santa Clara, CA 95054
24655	Gen Rad, Concord, MA 01742
25008	Vactite, Berkeley, CA 94710
56289	Sprague, North Adams, MA 01247
72136	Electromotive, Willimantic, CT 06226
72982	Erie, Erie, PA 16512
80294	Bourns Labs, Riverside, CA 92506
81349	Military Specifications
86684	RCA, Harrison, NJ 07029
90303	Mallory Bat., Tarrytown, NY 10591
94322	Tel Labs, Manchester, NH 03102
95146	Alco Elctrcs., Lawrence, MA 01843

GenRad

300 Baker Avenue
Concord, Massachusetts 01742

ATLANTA • 1 Dunwoody Park, Suite 107,
Atlanta, GA 30341 • Tel: 404 394-5380

***BOSTON** • (Sales) Bolton, MA 01740 • Tel: 617 64
(Service) Concord, MA 01742 • Tel: 617 369-8770
TWX: 710 347-1051

***CHICAGO** • 1067 E. State Parkway, Schaumburg, IL 60195
Tel: 312 884-6900 • TWX: 910 291-1209

DALLAS • 777 South Central Expressway, Suite 4-A,
Richardson, TX 75080 • Tel: 214 234-3357
TWX: 910 867-4771

DAYTON • 3300 South Dixie Drive, Dayton, OH 45439
Tel: 513 294-1500 • TWX: 810 459-1785

***LOS ANGELES** • P.O. Box 19500, 17361 Armstrong
Avenue, Irvine Industrial Complex, Irvine, CA 92714
Tel: 714 540-9830 • TWX: 910 595-1762

***NEW YORK** • 380 Midland Avenue,
Saddle Brook, NJ 07662 • Tel: (NJ) 201 791-8990,
(NY) 212 964-2722 • TWX: 710 988-2205

SAN FRANCISCO • 2855 Bowers Avenue,
Santa Clara, CA 95051 • Tel: 408 985-0662
TWX: 910 338-0291

Alaska: Tel: 907 279-5741

***WASHINGTON, DC** • 15 Firstfield Road,
Gaithersburg, MD 20760 • Tel: 301 948-7071
TWX: 710 828-9741

***CANADA** • 307 Evans Avenue, Toronto, Ontario M8Z 1K2
Tel: 416 252-3395

Montreal: 514 747-1052 • **Ottawa:** Zenith 88630

AR EAST • Bourne End
(06285) 2 66 11

nchon: (089) 40 18 01
rich: (01) 55 24 20

AMERICA

(MASS)

MP MASTER

MA20121

Printed in USA